



## Daily and Weekly Guide to the usage of Dairy Alkali & Acid Chemicals for Cleaning and Sanitisation.

### DIRECTIONS FOR USE:

#### **SITUATION:** **Milking Plant**

**PURPOSE:** DAILY Circulation Cleaner - milk stone eradication.

Standard solution: (AM) MORNING.

- |    |                             |  |
|----|-----------------------------|--|
| 1. | <b>WARM RINSE</b>           | Rinse plant with warm water.   |
| 2. | <b>HOT ALKALI DETERGENT</b> | Flush clean with ALKALI detergent (60°-80°C) 0.5 - 3.0% (HT-108 liquid), 1.0 to 1.5kg (RS-105 powder) per 100L water concentration with water for 10-15 minutes. |
| 3. | <b>WARM RINSE</b>           | Rinse plant with warm water.   |
| 4. | <b>DRAIN</b>                | Drain all water.   |

**PURPOSE:** DAILY Circulation Cleaner - complete milk stone eradication & sterilization.

Standard solution: (PM) EVENING.

- |    |                            |   |
|----|----------------------------|---|
| 1. | <b>WARM RINSE</b>          | Rinse plant with warm water.  |
| 2. | <b>HOT ACID DETERGENT</b>  | At a concentration 0.5 - 3.0% (HT-104 liquid) 1.0 to 1.5kg (RS-103 powder) per 100L at a temperature of 70°-80°C via Circulate at a frequency of weekly following the alkaline clean. |
| 3. | <b>WARM RINSE</b>          | Rinse plant with warm water.  |
| 4. | <b>SANITISE (OPTIONAL)</b> | PTSAN 5 sanitiser should be diluted with water and used at a rate of between 1:100 to 1:500 for c.i.p. pipe work and equipment.   |
| 5. | <b>COLD RINSE</b>          | Rinse plant with cold water.  |
| 4. | <b>DRAIN</b>               | Drain all water.  |

**SAFETY DIRECTIONS & FIRST AID:** please refer to your label. If poisoning occurs, contact a Doctor or Poisons Information Centre. Phone (Australia 13 1126). If swallowed do NOT induce vomiting. Give a glass of water. If skin contact occurs, remove contaminated clothing and wash skin thoroughly. If in eyes, hold eyes open, flood with water for at least 15 minutes and see a Doctor. For further information refer to the MSDS for the product.



Available from

**JAEGAR AUSTRALIA**

Factory 2/9 Tower Crt, Noble Park VIC. 3174. T: (03) 9769 1788 F: (03) 9769 0655

E: [jaegar@jaegaraustralia.com.au](mailto:jaegar@jaegaraustralia.com.au) W: [www.jaegaraustralia.com.au](http://www.jaegaraustralia.com.au)